





XO TYPE

1. Elevations are shown from exterior unless otherwise noted
2. Anchor/wall fastener
 - Location, spacing and quantity to be determined per design pressure requirements by structural engineer and/or certified test drawings

			
			
			
			
	TAEUN KIM	Jess Jeong	
	2019. 00. 00.		
REV.	DESCRIPTION		
	DRAWN BY(1)	DRAWN BY(2)	DRAWN BY(3)
	DATE		
PROJECT			
—			
ITEM NO.			
—			
PRODUCT NAME			
EWS95 OW			
INTERIOR EXTENSION			
QTY			
1			
VIEW			
EXTERIOR			
SCALE			
—			
DRAWING NO.			ISSUE