



<div>EAGON</div> <div>WINDOWS & DOORS</div> <div>COLTD</div>									
NOTE									
OPTIONS									
General Notes									
1. Elevations are shown from exterior unless otherwise noted									
2. Anchor/wall fastener – Location, spacing and quantity to be determined per design pressure requirements by structural engineer and/or certified test drawings									